

English

Español

Français

Defender[™] 3000 Series Base **Instruction Manual**

Deutsch

Italiano

Português

Svenska


Nederlands

Dansk

Polski

Čeština

Magyar





Defender Series Base EN-1

INTRODUCTION

This manual covers installation, and maintenance instructions for the OHAUS Defender [™] Series Base. Please read this manual completely before installation and operation.

SAFETY PRECAUTIONS

For safe and dependable operation of this product, please comply with the following precautions:

- Operate the base only under ambient conditions specified in these instructions
- Ensure that the load cell cable does not pose an obstruction or tripping hazard
- Do not operate the base in hazardous environments or unstable locations
- Do not drop loads on the base
- Do not lift the base by the top frame; always lift from the bottom frame when moving the base
- · Service should only be performed by authorized personnel

INSTALLATION

Unpacking

Unpack and inspect the product to make sure that all components have been included. The package includes the following:

Defender [™] Series Base
 Weighing Pan
 Instruction Manual


When purchased as a complete Defender Series Scale, the package will also include:

• Indicator • Column Kit (Front-mount Kit)

ASSEMBLY

Weighing Pan

Remove the shipping spacers, and place the weighing pan securely over the rubber load pads on the top frame of the base.



Note: Not included with some models

Wiring Connections

When connecting the base to an OHAUS indicator equipped with the matching circular connector, push the base connector onto the indicator connector and turn the locking ring clockwise to lock it in place.

When connecting the base to an indicator that does not have the matching connector, install the optional load cell cable adapter (P/N 30429931 sold separately) to the indicator using the wiring codes in Table 1. Then attach the load cell cable to the cable adapter.

Note: As an alternate wiring method, cut off the connector, strip the wires and attach them to the indicator using the wiring codes in Table 1.

() +33(0)3 20 55 19 11 () +32(0)16 73 55 72

The extension cable accessory (P/N: 30429931) cannot be used if the scale will be used in a legal for trade or legally controlled application, because there is no provision to seal the connection between the indicator and platform.

EN-2 Defender Series Base

If your base does not support EasyConnect[™], please refer to the indicator's manual for how to connect load cell connector.

TABLE 1. LOAD CELL CONNECTION

Type1. For model i-DxxxB1R, i-DxxxB1L base

FUNCTION	WIRE COLOR
+ Excitation	Red
- Excitation	Black
+ Signal	Blue
- Signal	White
Shield	Transparent

Type1. For model i-DxxxB1X, i-DxxxB1V base

FUNCTION	WIRE COLOR
+ Excitation	Red
- Excitation	Black
+ Signal	Green
- Signal	White
+ Sense	Blue
- Sense	Yellow
Shield	Transparent

Type2. For model i-DxxxC1x base


FUNCTION	WIRE COLOR
+ Excitation	Green
- Excitation	Black
+ Signal	Red
- Signal	White
+ Sense	Blue
- Sense	Brown
Shield	Yellow

Selecting the Location

To ensure accuracy, proper performance and safety, locate and operate the base on a stable, level surface. Avoid locations with rapid temperature changes or excessive dust, air currents, vibrations, electromagnetic fields or heat.

Level the base by adjusting the four leveling feet until the bubble in the level indicator is centered. A wrench may be needed to loosen the locking nut above each leveling foot. When the base is level, retighten the locking nuts up against the base to lock each foot into place.

Note: Ensure that the base is level each time its location is changed.



MAINTENANCE

Cleaning

The base components should be kept clean and free of excessive material build up.

• A damp cloth with water and a mild detergent may be used to wipe clean the external surfaces – do not use acids, alkalis, strong solvents or abrasive materials.

To maintain surface integrity, do not allow debris to remain on the surface of the painted or stainless steel base frame.

• Remove the pan and use fresh water to clean the base frame surface of any debris. Dry the base with a clean cloth or allow to air dry before replacing the pan. Repeat daily for best care.

Defender Series Base EN-3

Troubleshooting

Aside from installing components and leveling adjustments, the Defender Series Base does not require any other adjustments as shipped from the factory.

Operational difficulties that may be encountered can often be traced to simple causes such as:

- Loose or incorrect wiring connections
- Failure to remove the shipping spacers
- Obstructions to the base frame
- Unstable environments
- Incorrect calibration or setup of the indicator

If the troubleshooting section does not resolve or describe your problem, contact your authorized OHAUS service agent. For service assistance or technical support in the United States, call OHAUS toll-free between 8:00 AM and 5:00 PM EST. An OHAUS product service specialist will be available to provide assistance. Outside the USA, please visit the OHAUS web site to locate the OHAUS office nearest you.

TECHNICAL DATA

Technical Specifications

The technical data is valid under the following ambient conditions:

Operating temperature: -10°C to +40 °C (14 °F to 104 °F)

Relative humidity: maximum relative humidity 80% for temperatures up to 31 °C decreasing linearly to 50% relative

humidity at 40°C. Altitude: Up to 2,000m Pollution degree: 2

Note: Not all models may be available in your area. Check with your local OHAUS representative.

TABLE 2.1 SPECIFICATIONS

Model	i-D15B1R	i-D30B1R	i-D60B1R	i-D60B1L	i-D150B1L	i-D150B1X	i-D300B1X	i-D300B1V	i-D600B1V
Capacity	15 kg	30 kg	60 kg	60 kg	150 kg	150kg	300 kg	300 kg	600 kg
Approved Resolution					OIML 3000e				
Safe Overload Capacity					150% of capaci	ty			
Pan Dimensions		305 x 355 mm		420 x	420 x 550 mm 500 x 6		650 mm 600 x 800 mm		800 mm
Base Construction			Stainless St	eel platform w	th carbon steel fr	ame and rubbe	er leveling feet	•	
Load Cell Capacity	30 kg	50 kg	100 kg	100 kg	250 kg	250kg	500 kg	500kg	750kg
Load Cell Cable		2 m L x 4-wire 3 m L x 6-wire							
Load Cell Type		350 Ohm aluminum single point							
Load Cell Excitation					5-12V DC/AC				
Load Cell Rated Output		2 mV/V							
Net Weight	7 kg / 15.9 lb		13 kg / 28.8 lb		23 kg / 51.2 lb		41 kg / 90.6 lb		
Shipping Weight	10 kg / 22.5 lb			17 kg	/ 37.8 lb	27 kg /	58.9 lb	45 kg	/ 99.4 lb
Load Cell Protection	IP65								

EN-4 **Defender Series Base**

TABLE 2.2 SPECIFICATIONS

Model	i-D15C1R	i-D30C1R	i-D60C1R	i-D60C1L	i-D150C1L	i-D150C1X	i-D300C1X	
Capacity	15 kg	30 kg	60 kg	60 kg	150 kg	150 kg	300 kg	
Approved Resolution				OIML 30	100e			
Safe Overload Capacity				150% of ca	apacity			
Pan Dimensions		305 x 355 mm		420 >	< 550 mm	500 x	650 mm	
Base Construction		Stai	nless Steel platfor	m with stainless s	steel frame and rubbe	r leveling feet		
Load Cell Capacity	30 kg	50 kg	100 kg	100 kg	300 kg	300 kg	500 kg	
Load Cell Cable		2 m L x 6-wire						
Load Cell Type		350 Ohm Stainess steel single point						
Load Cell Excitation		5-15V DC/AC						
Load Cell Rated Output		2 mV/V						
Net Weight		8 kg / 17.1 lb		14 kg / 30.7 lb		27 kg / 58.5 lb		
Shipping Weight		11 kg / 23.7 lb		18 kg / 39.6 lb 30 kg / 60		/ 66.2 lb		
Load Cell Protection		IP67						

TABLE 2.3 SPECIFICATIONS

Model	i-D15B1R	i-D30B1R	i-D75B1R	i-D75B1L	i-D150B1L	i-D150B1X	i-D300B1X	i-D300B1V	i-D600B1V
Capacity	30 lb / 15 kg	60 lb / 30 kg	150 lb / 75 kg	150 lb / 75 kg	300 lb / 150 kg	300 lb / 150kg	600 lb / 300 kg	600 lb / 300 kg	1200 lb / 600 kg
Approved Resolution		NTEP and measurement Canada 3000e							
Safe Overload Capacity					150% of cap	acity			
Pan Dimensions		305 x 355 mm		420 x	420 x 550 mm 500 x 650 mi		50 mm	mm 600 x 800 mm	
Base Construction			Stainless S	teel platform	with carbon ste	el frame and rubb	er leveling feet		
Load Cell Capacity	30 kg	50 kg	100 kg	100 kg	250 kg	250kg	500 kg	500kg	750kg
Load Cell Cable		,	2 m L x 4-wire				3 m L :	x 6-wire	
Load Cell Type				350	Ohm aluminum	single point			
Load Cell Excitation					5-12V DC/	AC			
Load Cell Rated Output	2 mV/V								
Net Weight	7 kg / 15.9 lb			13 kg	/ 28.8 lb	23 kg / !	51.2 lb	41 kg /	90.6 lb
Shipping Weight	10 kg / 22.5 lb			17 kg	/ 37.8 lb	27 kg / !	58.9 lb	45 kg /	99.4 lb
Load Cell Protection	IP65								

TABLE 2.4 SPECIFICATIONS

Model	i-D15C1R	i-D30C1R	i-D75C1R	i-D75C1L	i-D150C1L	i-D150C1X	i-D300C1X		
Capacity	30 lb / 15 kg	60 lb / 30 kg	150 lb / 75 kg	150 lb / 75 kg	300 lb / 150 kg	300 lb / 150 kg	600 lb / 300 kg		
Approved Resolution		NTEP and measurement Canada 3000e							
Safe Overload Capacity				150% of cap	acity				
Pan Dimensions		305 x 355 mm		420 x 5	50 mm	500 x 6	50 mm		
Base Construction		St	ainless Steel platt	form with stainless ste	el frame and rubber le	eveling feet			
Load Cell Capacity	30 kg	50 kg	100 kg	100 kg	300 kg	300 kg	500 kg		
Load Cell Cable		2 m L x 6-wire							
Load Cell Type		350 Ohm Stainess steel single point							
Load Cell Excitation		5-15V DC/AC							
Load Cell Rated Output		2 mV/V							
Net Weight		8 kg / 17.1 lb		14 kg / 30.7 lb		27 kg / 58.5 lb			
Shipping Weight		11 kg / 23.7 lb		18 kg /	39.6 lb	30 kg /	66.2 lb		
Load Cell Protection		IP67							



Defender Series Base EN-5

Drawings




Figure 1. Defender Base Dimension Drawing.

TABLE 3. DIMENSIONS

	Α	В	С	D
Base	Pan Depth	Pan Width	Height of Pan to Surface of Table	Height of Pan
i-DxxxB1R	355 mm / 14.0 in	305 mm / 12.0 in	128 mm / 5.3 in	75mm / 3.0 in
i-DxxxB1L	550 mm / 21.7 in	420 mm / 16.5 in	140 mm / 5.5 in	80 mm / 3.1in
i-DxxxB1X	650 mm / 25.6 in	500 mm / 19.7 in	150 mm / 5.9 in	90 mm / 3.5 in
i-DxxxB1V	800 mm / 31.5 in	600 mm / 23.6 in	154 mm / 6.1 in	90 mm / 3.5 in
i-DxxxC1R	355 mm / 14.0 in	305 mm / 12.0 in	128 mm / 5.0 in	75mm / 3.0 in
i-DxxxC1L	550 mm / 21.7 in	420 mm / 16.5 in	140 mm / 5.5 in	80 mm / 3.1in
i-DxxxC1X	650 mm / 25.6 in	500 mm / 19.7 in	150 mm / 5.9 in	90 mm / 3.5 in

^{*}For leveling purposes, the feet may be extended up to an additional 15 mm.



EN-6 **Defender Series Base**

COMPLIANCE

Compliance to the following standards is indicated by the corresponding mark on the product.

Mark	Standard
CE	This product complies with the applicable harmonized standards of EU Directives 2011/65/EU (RoHS). The EU Declaration of Conformity is available online on the OHAUS website.
UK	This product complies with the applicable statutory standards of the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012. The UK Declaration of Conformity is available online on the OHAUS website.
	This product complies with the EU Directive 2012/19/EU (WEEE). Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment. For disposal instructions in Europe, refer to the OHAUS website.

ISO 9001 Registration

The management system governing the production of this product is ISO 9001 certified.

ACCESSORIES

TABLE 4. ACCESSORIES

Part Number	Description
30616409	Wheel Kit Defender Series SST
30372146	Wheel Kit Defender Series CS
30696595	Column Assembly 330mm SST i-D33
30696596	Column Assembly 680mm SST i-D33
30696597	Column Assembly 330mm CS i-D33
30696598	Column Assembly 680mm CS i-D33
30696599	Column Assembly 980mm CS i-D33
30696600	Front Mount Kit i-D33

LIMITED WARRANTY

OHAUS products are warranted against defects in materials and workmanship from the date of delivery through the duration of the warranty period. During the warranty period OHAUS will repair, or, at its option, replace any component(s) that proves to be defective at no charge, provided that the product is returned, freight prepaid, to OHAUS. This warranty does not apply if the product has been damaged by accident or misuse, exposed to radioactive or corrosive materials, has foreign material penetrating to the inside of the product, or as a result of service or modification by other than OHAUS. In lieu of a properly returned warranty registration card, the warranty period shall begin on the date of shipment to the authorized dealer. No other express or implied warranty is given by OHAUS Corporation. OHAUS Corporation shall not be liable for any consequential damages.

As warranty legislation differs from state to state and country to country, please contact OHAUS or your local OHAUS dealer for further details